



Backer Plate- Alfalfa

Variable Transmission

Cells Per Disc: 30 Cell Milo

Bulk Fill tank Settings: 8-10 (inches of water)

NOTE: "Reference Population" is used only to set rates and will not match the measured planter monitor population

Monitor will adjust meter RPM for row spacing			
*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)
150,000	19.1	120,750	15.4
147,750	18.8	118,500	15.1
145,500	18.6	116,250	14.8
143,250	18.3	114,000	14.5
141,000	18.0	111,750	14.3
138,750	17.7	109,500	14.0
136,500	17.4	107,250	13.7
134,250	17.1	105,000	13.4
132,000	16.8	102,750	13.1
129,750	16.6	100,500	12.8
127,500	16.3	98,250	12.5
125,250	16.0	96,000	12.2
123,000	15.7	93,750	12.0

Monitor will adjust meter RPM for row spacing			
*Reference Population	Application Rate (lbs/acre)	*Reference Population	Application Rate (lbs/acre)
91,500	11.7	62,250	7.9
89,250	11.4	60,000	7.7
87,000	11.1	57,750	7.4
84,750	10.8	55,500	7.1
82,500	10.5	53,250	6.8
80,250	10.2	51,000	6.5
78,000	10.0	48,750	6.2
75,750	9.7	46,500	5.9
73,500	9.4	44,250	5.6
71,250	9.1	42,000	5.4
69,000	8.8	39,750	5.1
66,750	8.5	37,500	4.8
64,500	8.2	35,250	4.5

Note: Seeding rates are approximations, environmental conditions can affect planting rates; Always field check populations.



*Successful Innovations for
Agriculture Since 1979*

800-368-7773
www.sidist.com
info@sidist.com